

ENGLISH ONLY



nixon®

TEAM DESIGNED CUSTOM BUILT

THE INSTRUCTIONS

DIGITALS

• **THE SMALL FULL NELSON**

WELCOME

YOU JUST BOUGHT A NIXON WATCH. HOW ABOUT THAT. WELCOME TO THE NIXON SIDE, A SIDE THAT'S ABOUT CUSTOM-BUILT PRODUCT, QUALITY, AND DURABILITY. WE'RE STOKED YOU SELECTED ONE OF OUR WATCHES. THE FACT THAT YOU BOUGHT A NIXON MEANS YOU CAN PROBABLY TELL TIME, BUT YOU MAY NOT BE FAMILIAR WITH ALL THE DOO-DADS AND FEATURES OF OUR WATCHES. SO IF YOU'RE STUCK, READ THROUGH THESE INSTRUCTIONS. OR GET YOUR FRIENDS TO READ THEM AND THEN THEY CAN TELL YOU WHAT'S UP.

THE SMALL FULL NELSON



MODES

THE MODES

LIGHT/RESET

MODE



SET

START/STOP

NORMAL TIME MODE

MONTH/DAY

ALARM ICON

AM/PM

HOURS/MINUTES



CHIME ICON

SECONDS/
OR DAY

THE MODES

NORMAL TIME

DUAL TIME (DU)

CHRONOGRAPH (CH)

COUNT DOWN (TR)

ALARM (AL)

PACER (PC)

THE BUTTONS

SET/LIGHT: Night light. Press and hold for setting.

MODE: This button changes between Time, Chrono, Chrono Recall, Timer, Dual Time and Alarm mode. Use to select setting when in setting modes.

LIGHT: Night Light. Also used to toggle between Lap and Split time in Chrono Recall.

STOP/RESET: This button stops and resets the Chrono. It toggles the Alarm on/off in Alarm mode. It toggles the Chime on/off.

START/LAP: This button starts the Chrono and records Chrono Laps. Used to (increase) numbers in Setting Modes. This button starts the Timer and is used to toggle between 12 and 24 hour modes

NORMAL TIME MODE

TO SET THE TIME

PUSH and **HOLD FOR 2 SECONDS** the **SET** BUTTON. The **DAY** will blink.

PUSH the **STRT/STP** button to scroll to the right day.

PUSH the **MODE** button. The **MINUTES** will blink.

PUSH the **STRT/STP** button to get to the right minute.

PUSH the **MODE** button. The **HOURS** will blink.

You know the drill by now: follow the same trick to set the **DAY**, **MONTH**, and **YEAR**.

PUSH the **STRT/STP** button to show the **day of the week** or **seconds**.

NORMAL TIME
DUAL MODE
ALARM ICON
AM/PM
DUAL TIME



CHIME ICON
SECONDS/
OR DAY

SPLIT HEADING
CHRONOGRAPH
MODE
HOURS
MINUTES



1/100 SEC.
SECONDS

DUAL TIME

PUSH the MODE button to enter DUAL TIME MODE. (You will see the DU indicator, telling you you've entered, DUAL TIME MODE)

PUSH and HOLD FOR 2 SECONDS the SET button.
The hour will blink.

PUSH the STRT/STP button to get to the right hour.

PUSH the SET button to set.

PUSH the STRT/STP button to switch to 24 hour display.

CHRONOGRAPH (STOP WATCH)

PUSH MODE to get to CHRONO MODE. (You will see the CH indicator telling you you've entered CHRONOGRAPH mode).

To Set

PUSH the LIGHT/SPLIT button to reset.

To Start

PUSH the STRT/STP button to stop and start.

For Splits

While the CHRONO is running

PUSH the LIGHT/SPLIT button for split. Your split will be displayed under the SPL1 heading.

PUSH the LIGHT/SPLIT button for up to four splits.

To Stop,

PUSH the STRT/STP button.

PUSH the SET button to scroll through your splits.

Man, you're fast.



COUNTDOWN TIMER

PUSH MODE to get to countdown mode. (You will see the **TR** indicator telling you you've entered **COUNTDOWN MODE**.)

To Set

- PUSH** and **HOLD FOR 2 SECONDS** the **SET** button. The minute will blink.
- PUSH** the **STRT/STP** button to adjust the minute.
- PUSH** the **MODE** button. The hour will blink.
- PUSH STRT/STP** to adjust the hour.
- PUSH** the **SET** button, your watch is now ready to countdown.

To Start the Countdown

1. **PUSH** the **STRT/STP** button.

Note: an alarm will sound when the countdown is complete. If you ignore it, it won't go away. The Countdown will begin to count **UP** so you can tell how long you've neglected your deadline. This will be indicate by the "**UP**" letters near the second numbers.

PRESS any button to stop beep.



ALARM MODE

PUSH the **MODE** button to go to **ALARM MODE** (you will see the **AL** indicator telling you you've entered **ALARM mode**).

To Set

- PUSH** and **HOLD** for 2 **SECONDS** the **SET** button. The minute will blink.
- PUSH** the **STRT/STP** button to adjust the minute.
- PUSH** the **MODE** button. The hour will blink.
- PUSH** the **STRT/STP** button to adjust the hour.
- PUSH** the **SET** button to set alarm.

To Activate Alarm.

In **ALARM MODE (AL)** push the **STRT/STP** button to turn alarm on/off. When "on" you will see the Nixon Logo.

To Turn off ringing Alarm:

Press the **STRT/STP** button.

To Activate Hourly Chime

In **ALARM MODE (AL)** push the **LIGHT** button to turn chime on/off. When "on" you will see the () mark.

NORMAL TIME

PACER
INDICATOR

PAGE

PACER MODE

PUSH MODE to get to PACER MODE.

PUSH the LIGHT/SPLIT button to select the right pace for you.

PUSH the STRT/STP button to start/stop the pace.

Hint: The PACER mode is excellent to use as a metronome or to keep a good walking/running pace.

WARRANTY

NIXON OFFERS A LIMITED WARRANTY ON DEFECTS IN MATERIALS AND WORKMANSHIP. THIS MEANS THAT IF YOUR WATCH MATERIALS AREN'T RIGHT OR THE WATCH ISN'T PUT TOGETHER CORRECTLY, WE'LL TAKE CARE OF IT. BUT, THIS DOESN'T MEAN THAT YOU CAN TRASH YOUR WATCH ON THE CURB OR LIFT TOWER OR RUN OVER IT WITH YOUR SKATE, BIKE, OR CAR OR ANY OTHER NORMAL WEAR AND TEAR AND EXPECT THE WORLD. THIS ALSO DOESN'T COVER BATTERIES, CRYSTAL, WATCH CASE, STRAP OR BRACELET, LOSS OR THEFT. IF YOU NEED THESE THINGS REPAIRED WE CAN DO IT FOR A NOMINAL CHARGE. **YOU WILL VOID THE WARRANTY IF YOU OPEN YOUR CASEBACK, PUSH THE BUTTONS UNDERWATER, OR FORGET TO SCREW DOWN THE CROWN.**

PROBLEMS? IF YOU'RE IN NORTH AMERICA, CALL US AT (760)-944-0900 DURING NORMAL BUSINESS HOURS, PACIFIC TIME AND WE CAN WORK IT OUT. IF YOU'RE SOMEWHERE ELSE IN THE WORLD, CONTACT THE STORE AT WHICH YOU BOUGHT YOUR NIXON AND THEY WILL POINT YOU IN THE RIGHT DIRECTION.